

INSTRUCTIONS FOR INSTALLING 8888, 12-8888, 8800, 12-8800, WS8800, 12-WS8800, HC-8800 and 12-HC8800 SERIES RIM EXIT DEVICES WITH ALL STANDARD TRIM

SARGENT®

ASSA ABLOY

FOR ASSISTANCE, CONTACT SARGENT AT 800-727-5477 or www.sargentlock.com

US PATENT No 268003 • CANADIAN PATENT No RD1981

ASSA ABLOY, the global leader
in door opening solutions

CAUTION!

BEFORE STARTING:

- READ INSTRUCTION SHEET CAREFULLY
- INSTALL MULLION IF USED
- DOOR SHOULD BE FITTED AND HUNG
- CHECK BOX LABEL FOR SIZE OF EXIT DEVICE


AVAILABLE STOCK LENGTHS

- Length "E": 32" door, no cut off required.
Can be cut to fit doors down to 24" wide.
- Length "F": 36" door, no cut off required.
Can be cut to fit doors down to 33" wide.
- Length "J": 42" door, no cut off required.
Can be cut to fit doors down to 37" wide.
- Length "G": 48" door, no cut off required.
Can be cut to fit doors down to 43" wide.

IMPORTANT:


*SURFACE OF THE DOOR WHERE EXIT DEVICE IS APPLIED MUST BE FLUSH.
CLEAR AWAY ANY RAISED PROJECTIONS TO ALLOW EXIT DEVICE TO REST ON FLAT SURFACE OF THE DOOR.

*IF SHIM KIT IS REQUIRED,
CONTACT YOUR
DISTRIBUTOR



WS8800 & 12-WS8800 Rim Exit Device (Shown Below)


- Requires 3 shims under the chassis and end bracket



HC8800 & 12-HC8800 Rim Exit Device (Not Shown)

- Requires 2 shims under the chassis and end bracket

16- Cylinder Lockdown (Exploded View for clarity)



Copyright © 2006, 2008, 2009, 2012 Sargent Manufacturing Company, an ASSA ABLOY Group company. All rights reserved. Reproduction in whole or in part without the express written permission of Sargent Manufacturing Company is prohibited.

A6770P

SCREWS USED FOR EXIT DEVICE INSTALLATION


SARGENT®

ASSA ABLOY


ATTENTION:

ALL SCREWS ARE SHOWN IN ACTUAL SIZE


SOME SCREWS WILL BE LONGER FOR DOORS OVER 1 3/4" THICK




ET MOUNTING SCREW (1-3/4" DOOR)
(1/4"-20 X 2-3/8" PH. FL. HD.
MACH. SCREW)



PULL TRIM MOUNTING SCREW
(1-3/4" DOOR)(1/4"-20 X 1-3/8"
PH. FL. HD. MACH. SCREW)



STRIKE MOUNTING SCREW, OUTER
(#10-24 X 3/4" PH. OV. HD.
MACH. SCREW) (STEEL FRAME)



GROMMET NUT



STAR WASHER




CUP WASHER




COVERS MOUNTING SCREW
(#8-32 X 5/16" WITH
#6 PH. OV. U'CUT HD.
MACH. SCREW, 6 PCS)




RAIL MOUNTING SCREW
(#8-32 X 3/8" PH. TRUSS
HEAD MACH. SCREW., 2 PCS)




CHASSIS MOUNTING SCREW
(1/4"-20 X 5/8" PH. FL. HD.
MACH. SCREWS., 2 PCS)




CHASSIS MOUNTING SCREW
(#10-24 X 3/4" PH. FL. HD.
MACH. SCREWS, 4 PCS)




CYLINDER MOUNTING SCREW (STD)
(#10-24 X 1-7/8" WITH
#8 PH. FL. HD. MACH. SCREW)




"LL" TYPE TRIM MOUNTING SCREW
(#10-32 X 5/8" PH. FILLISTER
HD. SEMS MACH. SCREW)




MOUNTING PLATE OR 649 STRIKE
MOUNTING SCREW, INNER
(#10-24 X 3/4" PH. RD.
HD. MACH. SCREW)




CHASSIS MOUNTING SCREW
FOR WOOD DOOR APPLICATION
(#10 X 1-1/4" PH. FL. HD.
WOOD SCREW, 4 PCS)



CHASSIS MOUNTING SCREW
FOR WOOD DOOR APPLICATION
(#14 X 1-1/2" PH. FL. HD.
WOOD SCREW, 2 PCS)



641 STRIKE MOUNTING SCREW
(#10 X 1-1/4" PH. OV. HD.
WOOD SCREW) (WOOD FRAME)



MOUNTING PLATE MOUNTING
SCREW (WOOD DOOR)
(#10 X 1-3/8" PH. RD. HD.
WOOD SCREW, 3 PCS)

THESE SCREWS PROVIDED FOR WOOD DOOR OR FRAME APPLICATIONS.

SCREW PACKS AND MISCELLANEOUS PARTS

PART No.	DESCRIPTION	PART No.	DESCRIPTION
68-3367	MOUNTING PACK (END CAP)	68-3922	MOUNTING PACK (CHASSIS)
68-3905	COVER SCREW PACK	809	TOUCH BAR REPLACEMENT KIT
68-2279	MOUNTING PACK (THRU BOLTING, 1-3/4" DOOR)	68-0879	END CAP
68-2280	MOUNTING PACK (THRU BOLTING, 2-1/4" DOOR)	68-0406	CHASSIS COVER
97-2953	STS SCREW PACK (1-3/4" DOOR)	97-2954	STS SCREW PACK (2-1/4" DOOR)
97-2955	PTB SCREW PACK (1-3/4" DOOR)	97-2966	PTB SCREW PACK (2-1/4" DOOR)
68-2596	HEX KEY DOGGING KIT	816	CYLINDER DOGGING KIT
01-4451	THRU BOLT 1/4"-20 X 2-3/8"	01-4372	THRU BOLT 1/4"-20 X 2 5/8"
01-4373	THRU BOLT 1/4"-20 X 2-7/8"	98-0028	LATCH BOLT SPRING

Copyright © 2006, 2008, 2009, 2012 Sargent Manufacturing Company, an ASSA ABLOY Group company. All rights reserved. Reproduction in whole or in part without the express written permission of Sargent Manufacturing Company is prohibited.

A6770P

FOR ADDITIONAL INFORMATION
CALL SARGENT CUSTOMER SERVICE AT:
1-800-727-5477

ASSA ABLOY, the global leader
in door opening solutions


FIRST

TOOLS REQUIRED FOR INSTALLATION:

1. MEASURING TAPE
2. POWER DRILL
3. DRILL BITS: 3/32", 11/32", 3/8", 3/4", #8, #25
4. TAPS: #10-24, 1/4-20
5. HACK SAW OR ANY POWER CUTTER (FOR CUTTING RAILS IF NECESSARY)
6. SCREWDRIVERS: PHILLIPS #2 AND #3
7. LEVEL


FOR RETROFIT DOOR PREPARATION, THE FOLLOWING MAY BE REQUIRED:
HOLE SAWS: 1-1/8", 1-3/8", 2-1/8"

A MARK VERTICAL AND HORIZONTAL REFERENCE LINES ON THE DOOR




B IDENTIFY TYPE OF INSTALLATION TO DETERMINE LOCATION OF VERTICAL REFERENCE LINE


PANIC EXIT DEVICE AND FIRE EXIT DEVICE (12- PREFIX)



DOUBLE DOOR WITH 980 MULLION AND 649 STRIKES




DOUBLE DOOR WITH 12-980 MULLION AND 649 STRIKES



SECOND


PREPARE DOOR

PLASTIC TEMPLATE (RECOMMENDED METHOD): INSTALL STRIKE FIRST, THEN EXIT DEVICE



1. APPLY PLASTIC TEMPLATE ON DOOR USING REFERENCE LINES AND 649 STRIKE
2. MARK THEN SPOT AND DRILL HOLES

PAPER TEMPLATE: INSTALL EXIT DEVICE FIRST, THEN STRIKE



1. APPLY PROPER TEMPLATE ON DOOR USING REFERENCE LINES. ATTACH IT WITH SUPPLIED TAPE
2. SPOT AND DRILL HOLES

FOR PANIC EXIT DEVICE:

ATTACH STRIKE WITH TWO (2) OUTER SCREWS AND TWO (2) STAR WASHERS PLACED UNDER THE STRIKE. ADJUST FOR PROPER POSITION AND TIGHTEN SCREWS SECURELY.

STAR WASHER

STRIKE MOUNTING SCREW, OUTER (#10-24 X 3/4" PH. OV. HD. MACH SCREW)

649 STRIKE

STRIKE MOUNTING SCREW, OUTER (#10-24 X 3/4" PH. OV. HD. MACH SCREW)

FOR FIRE EXIT DEVICE:

ATTACH STRIKE WITH TWO (2) OUTER SCREWS AND ADJUST FOR PROPER POSITION. INSTALL TWO (2) INNER SCREWS AND TIGHTEN ALL SCREWS SECURELY.

STRIKE MOUNTING SCREW, INNER (#10-24 X 3/4" PH. RD. HD. MACH SCREW)

649 STRIKE


SARGENT®**ASSA ABLOY**

ET TRIM APPLICATION
(SEE INSTRUCTION SHEET AND TEMPLATE PACKED WITH TRIM)


- A. ATTACH CHASSIS TO DOOR WITH (4) CHASSIS MOUNTING SCREWS (#10-24 X 3/4" PH. FL. HD. MACH. SCREWS) IN LOCATION SHOWN

(2) 1/4"-20 X 5/8" FLAT HEAD MACHINE SCREWS IN LOCATIONS SHOWN

- B. ATTACH ET CONTROL USING THE TWO (2) 1/4"-20 X 2-3/8" PH. FL. HD. MACH. SCREWS THROUGH THE APPROPRIATE MOUNTING HOLES IN CHASSIS



LL LEVER HANDLE TRIM REVERSIBLE (FOR 8888 AND 12-8888 ONLY)
(SEE INSTRUCTION SHEET AND TEMPLATE PACKED WITH TRIM)



LEVER HANDLE


SCREW

TUBE AND PLATE ASSEMBLY

MOUNTING BRACKET

STUD

**DUMMY TRIM FOR LHRB
EXIT DEVICE**





**DUMMY TRIM FOR RHRB
EXIT DEVICE**

THIRD (continuation)

PTB, FLL, FLW AND MAL PULL TRIM (PREP DOOR FOR TRIM TO BE USED)


1. ATTACH CHASSIS TO THE SURFACE OF DOOR WITH (4) #10-24 x 3/4" SCREWS
2. POSITION TRIM ON DOOR AND THROUGH-BOLT TRIM TO CHASSIS WITH (2) 1/4-20 x 5/8" LONG SCREWS
3. USING THE CUP WASHER, THROUGH-BOLT BOTTOM OF TRIM

SARGENT
ASSA ABLOY





PSB, FSL, FSW, MSL AND STS PULL TRIM BY CYLINDER APPLICATION

1. MOUNT CHASSIS TO DOOR WITH (6) CHASSIS MOUNTING SCREWS.
2. THROUGH-BOLT GROMMET NUT TO TOP CHASSIS MOUNTING HOLE.
3. THROUGH-BOLT TOP STUD TO BOTTOM CHASSIS MOUNTING HOLE.
4. THROUGH-BOLT BOTTOM STUD TO BOTTOM MOUNTING HOLE.
5. THROUGH-BOLT SARGENT CYLINDER TO CHASSIS THRU TRIM. IF SCREW IS TOO LONG, BREAK OFF AT NOTCHES AS NEEDED.
6. TIGHTEN ALL SCREWS SECURELY.



MOUNT SARGENT CYLINDER WITH 2 CYLINDER SCREWS (#10-24 X 1 7/8 WITH #8 PH. FL. HD MACH SCREW)


CHASSIS MOUNTING SCREWS 4 x #10-24 X 3/4 AND 2 x 1/4-20 X 5/8 PH. FL. HD. MACH SCREW



- CHECK BOX LABEL. IF CUTTING IS NOT REQUIRED, PROCEED TO STEP "B".
- IF CUTTING IS REQUIRED, CONTINUE WITH STEP "A".


A DETERMINE CUT OFF DIMENSION "X" BY SUBTRACTING 1-3/4" FROM DIMENSION "Y"

FOR DOORS WITH STILE:
RAIL MUST OVERLAP STILE
BY 1/2" MIN.



B 1. DEPRESS LIFT ARM INTO RAIL ASSEMBLY AND SLIDE RAIL ONTO CHASSIS.


2. ATTACH RAIL ASSEMBLY TO CHASSIS WITH TWO (2) #8 TRUSS HEAD MACHINE SCREWS. DO NOT TIGHTEN SCREWS.



3. LEVEL RAIL.

PLACE MOUNTING PLATE TIGHT AGAINST RAIL
AND ATTACH TO DOOR WITH TWO (2)
#10 ROUND HEAD SCREWS

4. TIGHTEN ALL SCREWS SECURELY.




FIFTH

(-53) LATCH BOLT MONITORING ADJUSTMENT

NOTE: THE LATCH BOLT SWITCH WILL COME PRE-SET FOR THE MOST COMMON APPLICATIONS. IF THE SENSITIVITY NEEDS TO BE ADJUSTED, FOLLOW THE STEPS BELOW.

1. LOOSEN SCREW AND NUT
2. ROTATE SWITCH (UP FOR QUICKER REACTION OR DOWN FOR SLOWER REACTION).
3. TIGHTEN SCREW AND NUT
4. CHECK OPERATION

NOTE: MAKE SURE SWITCH IS LOCATED ON THE MOUNTING POST AND THE SCREW AND NUT ARE SECURELY FASTENED





Using your mobile phone, scan this Microsoft® Tag.
Download the free mobile app at <http://gettag.mobi>

SIXTH

APPLY COVERS

ATTACH COVER TO CHASSIS
WITH FOUR (4) COVER
MOUNTING SCREWS
(#8-32 X 5/16 WITH #6 PH.
OV. HD. MACH. SCREW)
TIGHTEN SECURELY



ATTACH END CAP TO
MOUNTING PLATE
WITH TWO (2) COVER
MOUNTING SCREWS
TIGHTEN SECURELY